

EETI eGalaxGestureTool User Manual

eGalax_eMPIA Technology Inc.

2009/05/05 1.2.0.1902 beta version

EETI eGalaxGesture is a tool that allows user to utilize touchscreen with a single touch and trigger various actions, such as to maximize/minimize/close windows, show desktop, open specific programs, or emulate mouse wheel up/down, replace keyboard hotkeys, without any change to the platform.

Content

1	Gesture Setting → General Setting	2
2	General Setting Function.....	2
2.1	Enable Gesture Recognition	2
2.2	Notify on Click Down.....	2
2.3	Sensing Time	3
2.4	Sensitivity.....	3
2.5	Settings	3
3	Gesture Setting → Gesture Mapping	3
4	Gesture Mapping Function.....	3
4.1	Enable	4
4.2	Default actions	4
4.3	Open Program.....	4
4.4	Hotkey	5
5	Gesture Table	6


eGalaxGesture Tool contains two following files :



After execute eGalaxGesture.exe, eGalaxGesture will be added to and shown on the Taskbar. Double click the icon of eGalaxGesture, the tool will pop out.



1 Gesture Setting → General Setting :



2 General Setting Function :

2.1 Enable Gesture Recognition :

Enable/disable gesture recognition features.

2.2 Notify on Click Down :

By enabling this, a water-ripple notification will be shown when touch down.



2.3 Sensing Time :

The time period that the tool needs to recognize/capture the gesture, the gesture must be completed or finished within the set time period.

2.4 Sensitivity :


The lower the sensitivity is, the more accurate and precise the gesture needs to be.

2.5 Settings :

eGalaxGesture tool supports import or export the settings.

User can also reload the default setting.

3 Gesture Setting → Gesture Mapping :



4 Gesture Mapping Function :

Gesture Table :

Choose and click on the gesture that will be used.

4.1 Enable :

Enable/disable the chosen gesture, then appoint the desired actions listed below


4.2 Default actions :

eeGalaxGesture tool has set several default actions, include,

- No Action
- Open default web browser
- Open default mail client
- Open default media player (Windows media player)
- Mouse wheel up
- Mouse wheel down
- Maximize window
- Minimize window
- Close window
- Show desktop


4.3 Open Program :

User can appoint a gesture to open a specific program.



4.4 Hotkey :

User can appoint a gesture to replace/emulate keyboard hotkey. If there is no keyboard, user can use the On-Screen Keyboard by clicking “On-Screen Keyboard”.



5 Gesture Table :

eGalaxGesture supports 34 gestures, listed as below :

