



USER MANUAL

COMe-8X92

Computer-On-Module Express



Copyright

Copyright © 2012-2017 VIA Technologies Incorporated. All rights reserved.

No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise without the prior written permission of VIA Technologies, Incorporated.

Trademarks

All trademarks are the property of their respective holders.

Disclaimer

No license is granted, implied or otherwise, under any patent or patent rights of VIA Technologies. VIA Technologies makes no warranties, implied or otherwise, in regard to this document and to the products described in this document. The information provided in this document is believed to be accurate and reliable as of the publication date of this document. However, VIA Technologies assumes no responsibility for the use or misuse of the information (including use or connection of extra device/equipment/add-on card) in this document and for any patent infringements that may arise from the use of this document. The information and product specifications within this document are subject to change at any time, without notice and without obligation to notify any person of such change.

VIA Technologies, Inc. reserves the right to make changes to the products described in this manual at any time without prior notice.

Regulatory Compliance

FCC-A Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his personal expense.

Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice 2

Shielded interface cables and A.C. power cord, if any, must be used in order to comply with the emission limits.

Notice 3

The product described in this document is designed for general use, VIA Technologies assumes no responsibility for the conflicts or damages arising from incompatibility of the product. Check compatibility issue with your local sales representatives before placing an order.



Tested To Comply
With FCC Standards
FOR HOME OR OFFICE USE



Battery Recycling and Disposal

- ☐ Only use the appropriate battery specified for this product.
- ☐ Do not re-use, recharge, or reheat an old battery.
- ☐ Do not attempt to force open the battery.
- ☐ Do not discard used batteries with regular trash.
- ☐ Discard used batteries according to local regulations.



Safety Precautions

- ☐ Always read the safety instructions carefully.
- ☐ Keep this User's Manual for future reference.
- ☐ All cautions and warnings on the equipment should be noted.
- ☐ Keep this equipment away from humidity.
- ☐ Lay this equipment on a reliable flat surface before setting it up.
- ☐ Make sure the voltage of the power source and adjust properly 110/220V before connecting the equipment to the power inlet.
- ☐ Place the power cord in such a way that people cannot step on it.
- ☐ Always unplug the power cord before inserting any add-on card or module.
- ☐ If any of the following situations arises, get the equipment checked by authorized service personnel:
 - The power cord or plug is damaged.
 - Liquid has penetrated into the equipment.
 - The equipment has been exposed to moisture.
 - The equipment has not worked well or you cannot get it work according to User's Manual.
 - The equipment has dropped and damaged.
 - The equipment has obvious sign of breakage.
- ☐ Do not leave this equipment in an environment unconditioned or in a storage temperature above 60°C (140°F). The equipment may be damaged.
- ☐ Do not leave this equipment in direct sunlight.
- ☐ Never pour any liquid into the opening. Liquid can cause damage or electrical shock.
- ☐ Do not place anything over the power cord.
- ☐ Do not cover the ventilation holes. The openings on the enclosure protect the equipment from overheating.

Box Contents

COMe-8X92

- ☐ 1 x COMe-8X92 module
- ☐ 1 x Screw bag
- ☐ 1 x Fansink or Heat spreader (optional)

COMe-8X92 Starter Kit

- ☐ 1 x COMe-8X92 module with fansink
- ☐ 1 x COMEDB2 carrier board
- ☐ 1 x SATA cable
- ☐ 1 x Dual-port USB 2.0 cable
- ☐ 1 x COM cable
- ☐ 1 x LPT cable
- ☐ 1 x LVDS cable (optional)
- ☐ 1 x Inverter cable (optional)
- ☐ 1 x 12.1" LCM (optional)

Ordering Information

Model Name	Description
COMe-8X92	COM Express module with 1.2GHz VIA Nano® X2 E-Series CPU with HDMI, DisplayPort, VGA, LVDS, 4 x USB 3.0, 4 x USB 2.0, Gigabit Ethernet, 2 x SATA, 2 x PCIe, ATX power connector
COMEDB2	COMe-8X92 evaluation carrier board
99G42-01376A	Fansink for COMe-8X92
99G42-013886	Heat spreader for COMe-8X92
STK-C8X92-00A0	COMe-8X92 starter kit
STK-C8X92-01A0	COMe-8X92 starter kit with panel

Table of Contents

1. Product Overview	1
1.1. Key Components.....	1
1.1.1. VIA Nano® X2 E-Series Processor	1
1.1.2. VIA VX900 System Chipset.....	1
1.2. Product Specifications	2
1.3. Layout Diagram	5
2. Hardware Installation	6
2.1. CPU	6
2.1.1. CPU Fan Connector: CPUFAN	7
2.2. Memory Module Installation.....	8
2.2.1. Memory Slot: SODIMM	8
2.2.2. Installing the Memory	9
2.2.3. Removing a Memory Module	10
2.3. Installing fansink/heat spreader on COMe-8X92 module.....	11
2.4. Installing COMe-8X92 module to COMEDB2 carrier board	12
3. BIOS Setup Utility.....	17
3.1. Entering the BIOS Setup Utility	17
3.2. Control Keys	17
3.3. Navigating the BIOS Menus.....	17
3.4. Getting Help	17
3.5. System Overview	18
3.5.1. AMIBIOS.....	18
3.5.2. Processor	18
3.5.3. System Memory	18
3.5.4. System Time	18
3.5.5. System Date.....	18
3.6. Advanced Settings.....	19
3.6.1. CPU Configuration	20
3.6.2. IDE Configuration	21
3.6.2.1. Hard Disk Information.....	21
3.6.2.2. Channel Operating Mode.....	21
3.6.3. SuperIO Configuration	22
3.6.3.1. Serial Ports 1 to 2	22
3.6.3.2. Parallel Port Address.....	22
3.6.3.3. Parallel Port Mode	22
3.6.3.4. Parallel Port IRQ	22
3.6.4. Hardware Health Configuration.....	23
3.6.5. ACPI Configuration	24
3.6.5.1. Suspend Mode	24
3.6.5.2. ACPI Version Features	24
3.6.5.3. ACPI APIC Support.....	24
3.6.6. APM Configuration.....	25
3.6.6.1. Power Button Mode	25

3.6.6.2.	Restore on AC/Power Loss	25
3.6.6.3.	Wake-Up Key	25
3.6.6.4.	Wake-Up Password	26
3.6.6.5.	Resume on Software RTC Alarm	26
3.6.6.6.	Resume on RTC Alarm	26
3.6.6.7.	RTC Alarm Date (Days)	26
3.6.6.8.	System Time	26
3.6.7.	Spread Spectrum Configuration	27
3.6.7.1.	Spread Spectrum Setting	27
3.6.8.	USB Configuration	27
3.6.8.1.	OnChip UHCI Device	28
3.6.8.2.	OnChip EHCI Device	28
3.6.8.3.	Legacy USB Support	28
3.6.8.4.	USB 2.0 Controller Mode	28
3.6.9.	CRB Configuration	28
3.6.9.1.	VIA USB Wireless LAN Control	28
3.7.	Advanced PCI/PnP Settings	29
3.7.1.	Clear NVRAM	29
3.7.2.	Plug & Play O/S	29
3.7.3.	PCI Latency Timer	29
3.7.4.	Allocate IRQ to PCI VGA	29
3.7.5.	Palette Snooping	30
3.7.6.	PCI IDE BusMaster	30
3.7.7.	OffBoard PCI/ISA IDE Card	30
3.7.8.	IRQ3~15	30
3.7.9.	DMA Channel 0~7	30
3.7.10.	Reserved Memory Size	30
3.7.11.	HotPlug Reserve I/O Port Size	30
3.7.12.	HotPlug Reserve Memory Size	30
3.7.13.	HotPlug Reserve PFMemory Size	30
3.8.	Boot Settings	31
3.8.1.	Boot Settings Configuration	31
3.8.1.1.	Quick Boot	31
3.8.1.2.	Quiet Boot	32
3.8.1.3.	AddOn ROM Display Mode	32
3.8.1.4.	Bootup Num-Lock	32
3.8.1.5.	Wait for 'F1' if Error	32
3.8.1.6.	Hit 'DEL' Message Display	32
3.8.1.7.	Interrupt 19 Capture	32
3.9.	Security Settings	33
3.9.1.	Change Supervisor Password	33
3.9.2.	Password Check	33
3.10.	Advanced Chipset Settings	34
3.10.1.	North Bridge VIA VX900 Configuration	34
3.10.1.1.	NB HDAudio Codec 1	34
3.10.1.2.	DRAM Clock/Timing Configuration	35
3.10.1.2.1.	DRAM Clock	35



3.10.1.3.	OnChip VGA Configuration	36
3.10.1.3.1.	Hide D1F1	36
3.10.1.3.2.	VGA Share Memory (Frame Buffer)	36
3.10.1.3.3.	CPU Direct Access Frame Buffer	36
3.10.1.3.4.	Select Display Device Control	36
3.10.1.3.5.	Select Display Device 1 and 2	36
3.10.1.3.6.	Panel Type	37
3.10.1.3.7.	Backlight Control by VX900	37
3.10.1.3.8.	Backlight Control by AD5301	37
3.10.1.4.	PCIE-NB Configuration	38
3.10.1.4.1.	Reset PCIE When Link Fail	38
3.10.1.4.2.	Reset PE0 When Link Fail	38
3.10.1.4.3.	Reset PE1 When Link Fail	38
3.10.1.4.4.	Reset PE2 When Link Fail	38
3.10.1.4.5.	Reset PE3 When Link Fail	38
3.10.1.4.6.	PCIE Target Link Speed	38
3.10.1.4.7.	PCIE Root Port	38
3.10.1.4.8.	PCIE PE0 Control	38
3.10.1.4.9.	PCIE PE1 Control	38
3.10.1.4.10.	PCIE PE2 Control	38
3.10.1.4.11.	PCIE PE3 Control	38
3.10.2.	South Bridge VIA VX900 Configuration	39
3.10.2.1.	SATA Gen2 Support	39
3.10.2.2.	OnChip HDAC Device	39
3.10.2.3.	Serial ATA Controller	39
3.10.2.4.	OnChip UART Mode	39
3.10.2.5.	SDIO Host Controller	39
3.10.2.6.	HPET Support	39
3.10.2.7.	WATCHDOG Timer Enable	39
3.11.	Exit Options	40
3.11.1.	Save Changes and Exit	40
3.11.2.	Discard Changes and Exit	40
3.11.3.	Discard Changes	40
3.11.4.	Load Optimal Defaults	40
4.	Software and Technical Supports	41
4.1.	Microsoft and Linux Support	41
4.1.1.	Driver Installation	41
4.1.1.1.	Microsoft Driver Support	41
4.1.1.2.	Linux Driver Support	41
4.2.	Technical Supports and Assistance	41
Appendix A.	COMEDB2 Carrier Board	42
A.1.	Board Specifications	42
A.2.	External I/O Connectors	44
A.2.1.	Front Panel I/O	44
A.2.2.	Rear Panel I/O	44



A.3. COMEDB2 Layout Diagram	45
A.3.1. Onboard Slots, Buttons and Power Connectors	45
A.3.2. Onboard Pin headers and Connectors	46
A.3.2.1. Pin Headers and Connectors pin definition.....	48
A.3.3. Onboard Jumpers	53
A.3.3.1. Jumper Settings.....	54

List of Figures

Figure 1: Layout diagram of the COMe-8X92 module (top view)	5
Figure 2: Layout diagram of the COMe-8X92 module (bottom view)	5
Figure 3: CPU with fansink	6
Figure 4: CPU with heat spreader	6
Figure 5: CPU fan connector diagram	7
Figure 6: DDR3 SODIMM slot diagram	8
Figure 7: Inserting the memory module	9
Figure 8: Locking the memory module	9
Figure 9: Disengaging the SODIMM locking clips	10
Figure 10: Removing the memory module	10
Figure 11: Fansink/Heat spreader mounting points	11
Figure 12: Aligning the fansink on module	11
Figure 13: Aligning the heat spreader on module	11
Figure 14: Carrier board mounting points and connectors	12
Figure 15: Installing hex spacers on the carrier board	13
Figure 16: Aligning COMe-8X92 (with fansink) and carrier board mounting points	14
Figure 17: Aligning COMe-8X92 (with heats preader) and carrier board mounting points	14
Figure 18: Securing COMe-8X92 (with fansink) module	15
Figure 19: Securing COMe-8X92 (with heat spreader) module	16
Figure 20: Illustration of the Main menu screen	18
Figure 21: Illustration of the Advanced Settings screen	19
Figure 22: Illustration of the CPU Configuration screen	20
Figure 23: Illustration of IDE Configuration screen	21
Figure 24: Illustration of Primary IDE Master screen	21
Figure 25: Illustration of SuperIO Configuration screen	22
Figure 26: Illustration of Hardware Health Configuration screen	23
Figure 27: Illustration of ACPI Configuration screen	24
Figure 28: Illustration of APM Configuration screen	25
Figure 29: Illustration of Spread Spectrum Configuration screen	27
Figure 30: Illustration of USB Configuration screen	27
Figure 31: Illustration of CRB Configuration screen	28
Figure 32: Illustration of Advanced PCI/PnP Settings screen	29
Figure 33: Illustration of Boot Settings screen	31
Figure 34: Illustration of Boot Settings Configuration screen	31
Figure 35: Illustration of Security Settings screen	33
Figure 36: Illustration of Advanced Chipset Settings screen	34
Figure 37: Illustration of North Bridge VIA VX900 Configuration screen	34
Figure 38: Illustration of DRAM Frequency/Timing Configuration screen	35
Figure 39: Illustration of OnChip VGA Configuration screen	36
Figure 40: Illustration of PCIE-NB Configuration screen	38
Figure 41: Illustration of South Bridge VIA VX900 Configuration screen	39
Figure 42: Illustration of Exit Options screen	40
Figure 43: Front panel I/O	44
Figure 44: Rear panel I/O	44
Figure 45: COMEDB2 slots buttons and power connectors layout	45

Figure 46: COMEDB2 pin headers and connectors.....	46
Figure 47: COMEDB2 jumpers layout.....	53

List of Tables

Table 1: CPU fan connector pinout	7
Table 2: Serial port addresses and IRQs	22
Table 3: Layout diagram description table of the COMEDB2 (pin headers and connectors)	47
Table 4: Layout diagram description table of the COMEDB2 (jumpers)	53

1. Product Overview

The VIA COMe-8X92 is a compact and highly integrated Type 6 COM Express module. It comes with an integrated 1.2GHz VIA Nano® X2 E-Series (or 1.0GHz VIA QuadCore E-Series) processor, boasting of ultra-low power consumption, cool and quiet operation, and enhanced multi-tasking ability.

The COMe-8X92 is based on the VIA VX900 chipset featuring the Integrated VIA C-9 HD DX9 3D/2D graphics processor and unified video decoding accelerator for rich digital media performance. It provides support for extensive connectivity options, including audio, USB, Ethernet, and graphics, through board-to-board connectors to an I/O carrier board.

1.1. Key Components

1.1.1. VIA Nano® X2 E-Series Processor

The VIA Nano® X2 E-Series is a dual-core processor and 64-bit superscalar processor in x86 platform using a 40 nanometer process technology. It delivers an energy-efficient, powerful performance, with cool and quiet operation all within an ultra-compact NanoBGA2 package measuring 21mm x 21mm.

VIA Nano® X2 E-Series processor offers an excellent performance on multitasking application that makes it perfect for embedded system applications such as industrial PCs, test machines, measuring equipment, digital signage, medical PCs, monitoring systems, gaming machines, in-vehicle entertainment, and etc. The VIA Nano® X2 E-Series processor also boasts of immersive multimedia performance, connectivity and computing applications

1.1.2. VIA VX900 System Chipset

The VIA VX900 Unified Digital Media Chipset is designed to enable high quality digital video streaming and DVD playback in a new generation of fanless, small form factor PCs and IA devices. The VIA VX900 features VIA C-9 HD DX9 3D/2D video processor with MPEG-2, WMV9, VC1, and H.264 video decoding acceleration, DDR3 1066/800 MHz support, motion compensation and dual display support to ensure a rich overall entertainment experience. The VIA VX900 is packed in single chip package measuring 33mm x 33mm.

1.2. Product Specifications

Core

Processor

- 1.2GHz VIA Nano® X2 E-Series processor
- 1.0GHz VIA QuadCore E-Series processor (manufacturing option)

Chipset

- VIA VX900 all-in-one system processor

System Memory

- 1 x DDR3 1066 SODIMM horizontal type slot
- Supports up to 4GB memory size

BIOS

- AMI BIOS,
- 4/8Mbit SPI flash memory

Operating System

- Windows 7
- Windows Embedded System 7
- Windows CE 6.0
- Linux
- QNX Neutrino
- VXWorks 6.9

Hardware Monitoring

- CPU temperature reading
- CPU fan speed reading
- System voltage monitoring

Watchdog Timer

- Software Programmable

Expansion Bus

- 1 x PCIe Gen2 x4
- 1 x PCIe Gen2 x1

Video

VGA

- Integrated VIA C-9 HD DX9 3D/2D graphics with MPEG-2, WMV9, VC1 and H.264 video decoding acceleration

CRT Interface

- 1 x Analog VGA port supports up to 2560 x 1600 resolution

LVDS Interface

- 1 x LVDS channel supports single-channel 18-bit or 24-bit LVDS panel

HDMI® Interface

- 1 x HDMI® port

	DisplayPort Interface <ul style="list-style-type: none"> 1 x DisplayPort
	Expansion Buses <ul style="list-style-type: none"> 1 x Digital Video Output port for external HDMI®/LVDS/DVI transmitter or TV encoder
Ethernet	Chipset <ul style="list-style-type: none"> VIA VT6130 Gigabit Ethernet controller
Input/Output	Audio <ul style="list-style-type: none"> Supports 1 HD audio digital interface LAN <ul style="list-style-type: none"> Supports 1 Gigabit Ethernet port USB <ul style="list-style-type: none"> Supports up to 4 USB 3.0 ports (by VLI VL800 controller) Supports up to 4 USB 2.0 ports SATA <ul style="list-style-type: none"> Supports up to 2 SATA 3.0Gbps ports Serial <ul style="list-style-type: none"> Supports 2 Serial ports with TX and RX signal Expansion Buses <ul style="list-style-type: none"> Supports 1 SMBus interface Supports 1 I²C bus Supports 1 SDIO interface (default) Supports 1 GPIO interface with 4 INs and 4 OUTs, shared with SDIO (by request) Supports 1 LPC bus interface Supports SPI Supports ExpressCard, speaker out, reset function, thermal protection, suspend/wake signals, power button, power good and fan control signals
Mechanical and Environment	COM Express Compliance <ul style="list-style-type: none"> COM Express™ Type 6, Basic Module Dimension <ul style="list-style-type: none"> 95mm x 95mm (3.73" x 3.73") Operating Temperature <ul style="list-style-type: none"> 0°C ~ 50°C Storage Temperature <ul style="list-style-type: none"> -40°C ~ 70°C Operating Humidity

- 0% ~ 95% (relative humidity; non-condensing)

**Note:**

As the operating temperature provided in the specifications is a result of the test performed in VIA's chamber, a number of variables can influence this result. Please note that the working temperature may vary depending on the actual situation and environment. It is highly suggested to execute a solid testing and take all the variables into consideration when building the system. Please ensure that the system runs well under the operating temperature in terms of application.

1.3. Layout Diagram




Figure 1: Layout diagram of the COMe-8X92 module (top view)




Figure 2: Layout diagram of the COMe-8X92 module (bottom view)

2. Hardware Installation

2.1. CPU

The VIA COMe-8X92 module is designed with the VIA Nano® X2 E-Series 1.2GHz processor. Other processor option (e.g., VIA QuadCore E-Series 1.0GHz processor) is also available as manufacturing options. The VIA Nano® X2 E-Series processor requires a fansink/heat spreader (plus user's own thermal solution) to provide sufficient cooling.




Figure 3: CPU with fansink




Figure 4: CPU with heat spreader

2.1.1. CPU Fan Connector: CPUFAN

CPU fan run on +12V and maintains system cooling.




Figure 5: CPU fan connector diagram

Pin	Signal
1	FAN_IN
2	PWM_OUT
3	GND

Table 1: CPU fan connector pinout

2.2. Memory Module Installation

2.2.1. Memory Slot: SODIMM

The VIA COMe-8X92 has one DDR3 SODIMM memory slot (horizontal type) that can accommodate a maximum of 4GB memory size. The memory slot is labeled as "SODIMM1". The location of the DDR3 memory slot is shown below.




Figure 6: DDR3 SODIMM slot diagram

2.2.2. Installing the Memory

The SODIMM memory slot is located under the fansink. Take off first the fansink before installing the memory.

Step 1

Align the notch on the memory module with the protruding wedge on the SODIMM slot. Insert the memory module into the slot at 30 degrees angle.




Figure 7: Inserting the memory module

Step 2

Push down until the memory module snaps into place. The memory slot has two locking mechanisms that will click once the memory module has been fully inserted.




Figure 8: Locking the memory module

2.2.3. Removing a Memory Module

Step 1

Disengage the locking clasps at both ends of the memory slot.




Figure 9: Disengaging the SODIMM locking clips

Step 2

When the locking clips have cleared, the SODIMM memory module will automatically pop up. Remove the memory module.




Figure 10: Removing the memory module

2.3. Installing fansink/heat spreader on COMe-8X92 module

Step 1

Locate the fansink/heat spreader mounting holes.




Figure 11: Fansink/Heat spreader mounting points

Step 2

Align the fansink/heat spreader over the mounting holes on COMe-8X92 module.




Figure 12: Aligning the fansink on module




Figure 13: Aligning the heat spreader on module



Note:

Make sure the thermal pad or thermal paste has been applied on top of the processor and chipset before installing the fansink/heat spreader.

2.4. Installing COMe-8X92 module to COMEDB2 carrier board

Step 1

Locate the carrier board mounting points (x4) and the connectors (x2).




Figure 14: Carrier board mounting points and connectors

Step 2

Install the hex spacer onto the carrier board. The hex spacer must be placed on top of the board. From the bottom of the board, tighten the hex spacers by using the M2.5x4mm screws (x4).




Figure 15: Installing hex spacers on the carrier board

Step 3

Align the pin connectors and mounting points of the COMe-8X92 into the connectors and hex spacers on the carrier board respectively.




Figure 16: Aligning COMe-8X92 (with fansink) and carrier board mounting points




Figure 17: Aligning COMe-8X92 (with heats preader) and carrier board mounting points

Step 4

Press down the COMe-8X92 module until the pin connectors have been fully inserted into the connectors.

Step 5

Secure the COMe-8X92 module with the fansink/heat spreader by screwing and tightening four 10mm screws (torque: 3kgfcm) in sequence.




Figure 18: Securing COMe-8X92 (with fansink) module




Figure 19: Securing COMe-8X92 (with heat spreader) module

Step 6

Connect the CPU fan connector cable.

3. BIOS Setup Utility

3.1. Entering the BIOS Setup Utility

Power on the computer and press **Delete** during the beginning of the boot sequence to enter the BIOS Setup Utility. If the entry point has passed, restart the system and try again.

3.2. Control Keys

Up	Move up one row
Down	Move down one row
Left	Move to the left in the navigation bar
Right	Move to the right in the navigation bar
Enter	Access the highlighted item / Select the item
Esc	Jumps to the Exit screen or returns to the previous screen
Page up / +¹	Increase the numeric value
Page down / -¹	Decrease the numeric value
F1	General help ²
F10	Save all the changes and exit



Notes:

1. Must be pressed using the 10-key pad.
2. The General help contents are only for the Status Page and Option Page setup menus.

3.3. Navigating the BIOS Menus

The main menu displays all the BIOS setup categories. Use the <Left>/<Right> and <Up>/<Down> arrow keys to select any item or sub-menu. Descriptions of the selected/highlighted category are displayed at the bottom of the screen.

The small triangular arrowhead symbol next to a field indicates that a sub-menu is available (see figure below). Press <Enter> to display the sub-menu. To exit the sub-menu, press <Esc>.

3.4. Getting Help

The BIOS Setup Utility provides a “**General Help**” screen. This screen can be accessed at any time by pressing **F1**. The help screen displays the keys for using and navigating the BIOS Setup Utility. Press **Esc** to exit the help screen.

3.5. System Overview

The System Overview screen is the default screen that is shown when the BIOS Setup Utility is launched. This screen can be accessed by traversing the navigation bar to the “Main” label.




Figure 20: Illustration of the Main menu screen

3.5.1. AMIBIOS

The content in this section of the screen shows the current BIOS version, build date, and ID number.

3.5.2. Processor

This content in this section shows the CPU information that has been detected.

3.5.3. System Memory

This section shows the amount of available memory that has been detected.

3.5.4. System Time

This section shows the current system time. Press **Tab** to traverse right and **Shift+Tab** to traverse left through the hour, minute, and second segments. The **+** and **-** keys on the number pad can be used to change the values. The time format is [Hour: Minute: Second].

3.5.5. System Date

This section shows the current system date. Press **Tab** to traverse right and **Shift+Tab** to traverse left through the month, day, and year segments. The **+** and **-** keys on the number pad can be used to change the values. The weekday name is automatically updated when the date is altered. The date format is [Weekday, Month, Day, Year].

3.6. Advanced Settings

The Advanced Settings screen shows a list of categories that can provide access to a sub-screen. Sub-screen links can be identified by the preceding right-facing arrowhead.




Figure 21: Illustration of the Advanced Settings screen

The Advanced Settings screen contains the following links:

- CPU Configuration
- IDE Configuration
- SuperIO Configuration
- Hardware Health Configuration
- ACPI Configuration
- APM Configuration
- Spread Spectrum Configuration
- USB Configuration
- CRB Configuration

3.6.1. CPU Configuration

The CPU Configuration screen shows detailed information about the built-in processor.

BIOS SETUP UTILITY	
Advanced	
Configure advanced CPU settings Module Version 01.0C	
<hr/>	
Manufacturer : VIA VIA Nano U3100 (1.6GHz Capable) Speed(FSB 200MHz * 8): 1600MHz Core : 1 Cache L1 : 128 KB Cache L2 : 1024 KB Microcode revision : 3A PMON Support: : N/A	
<div><div>←→ ↑↓ + - F1 F10 ESC</div><div>Select Screen Select Item Change Option General Help Save and Exit Exit</div></div>	
V02.69 (C) Copyright 1985-2010, American Megatrends, Inc.	

Figure 22: Illustration of the CPU Configuration screen

The IDE Configuration screen shows links to the primary IDE Master and primary IDE Slave hard drive information screens.



When a hard drive is detected, the hard drive's detailed information can be displayed on the Primary IDE Master/Slave sub-screen.



The Channel Operating Mode has two options: Compatibility and Native PCI.

3.6.3. SuperIO Configuration

The SuperIO Configuration screen shows the specific addresses, IRQs and types of the onboard serial ports.




Figure 25: Illustration of SuperIO Configuration screen

3.6.3.1. Serial Ports 1 to 2

This option allows the user to select the Serial Port 1 and 2 base I/O address and interrupt request address. The Serial Port 1 to 2 has three selectable options.

Port	Address and IRQs
1	3F8/IRQ4, 3E8/IRQ4, 2E8/IRQ3
2	2F8/IRQ3, 3E8/IRQ4, 2E8/IRQ3

Table 2: Serial port addresses and IRQs

3.6.3.2. Parallel Port Address

This specifies the I/O port address and IRQ of the parallel port. The parallel port has four options: Disabled, 378, 278 and 3BC

3.6.3.3. Parallel Port Mode

This specifies the parallel port mode. The parallel port mode has five options: Normal, Bi-Directional, ECP, EPP, EPP+ECP.

3.6.3.4. Parallel Port IRQ

This specifies the parallel port interrupt request address. The parallel port IRQ has 2 options: IRQ5 and IRQ7.

3.6.4. Hardware Health Configuration

The Hardware Health Configuration screen displays the monitored aspects of the mainboard such as CPU temperature, system temperature, fan speeds, and voltages of the power planes.

BIOS SETUP UTILITY	
Advanced	
VT1211 Hardware Health Event Monitoring	
+1.0Vin (UCH3)	:1.050 V
+5VSBin (UCH1)	:5.035 V
+3.3Vin (UCH4)	:3.407 V
+5Vin (UCH2)	:5.087 V
+12Vin (UCH5)	:12.018 V
F75308 Hardware Health Event Monitoring	
CPU Temperature	:33°C/91°F
CPU FAN Reading	:4123 RPM
VCORE	:1.062 V
+1.5V	:1.500 V
+3.3V	:3.192 V
+VCCP	:1.034 V
<div>←→ Select Screen ↑↓ Select Item F1 General Help F10 Save and Exit ESC Exit</div>	
V02.69 (C) Copyright 1985-2010, American Megatrends, Inc.	

Figure 26: Illustration of Hardware Health Configuration screen

3.6.5. ACPI Configuration

ACPI grants the operating system direct control over system power management. The ACPI Configuration screen can be used to set a number of power management related functions.




Figure 27: Illustration of ACPI Configuration screen

3.6.5.1. Suspend Mode

The Suspend Mode field has three selectable options.

S1(POS)

S1/Power On Suspend (POS) is a low power state. In this state, no system context (CPU or chipset) is lost and hardware maintains all system contexts.

S3(STR)

S3/Suspend To RAM (STR) is a power-down state. In this state, power is supplied only to essential components such as main memory and wakeup-capable devices. The system context is saved to main memory, and context is restored from the memory when a "wakeup" event occurs.

Auto

When the Suspend Mode is set to Auto, the operating system will control the power state.

3.6.5.2. ACPI Version Features

The ACPI Version Features enables the BIOS to support the designated ACPI specification. There are three versions to choose from: ACPI v1.0, ACPI v2.0, and ACPI v3.0.

3.6.5.3. ACPI APIC Support

The ACPI APIC Supports enables the ACPI support in APIC. The ACPI APIC Supports has two options: Enabled and Disabled. When select "Enabled", the ACPI APIC table pointer includes in the Root System Description Table (RSDT) pointer lists. When select "Disabled", support for this feature will be unavailable.

3.6.6. APM Configuration

APM enables the operating system to co-work with the BIOS to control the system power management. The APM Configuration screen can be used to set a number of power management functions.




Figure 28: Illustration of APM Configuration screen

3.6.6.1. Power Button Mode

The Power Button Mode has three options.

On/Off

When On/Off is selected, pressing the power button will instantly cause the system to power on or off.

Standby

When Standby is selected; the power button must be pressed and held down for 4 seconds before the system will power off.

Suspend

When Suspend is selected, pressing the power button will instantly cause the system to enter suspend mode.

3.6.6.2. Restore on AC/Power Loss

Restore on AC/Power Loss defines how the system will respond after AC power has been interrupted while the system is on. There are three options.

Power Off

The Power Off option keeps the system in an off state until the power button is pressed again.

Power On

The Power On option restarts the system when the power has returned.

Last State

The Last State option restores the system to its previous state when the power was interrupted.

3.6.6.3. Wake-Up Key

The Wake-Up Key feature can only be set when **Resume on PS/2 KBC** is set to "S3" or "S3/S4/S5". Otherwise, this feature will be not selectable. This feature has two options.

Any Key

The Any Key option enables any key on the keyboard to trigger the Wake-Up event.

Specific Key

The Specific Key option unlocks the **Wake-Up Password** feature.

3.6.6.4. Wake-Up Password

The Wake-Up Password feature can only be set when the **Wake-Up Key** feature is set to "Specific Key". This feature enables the user to specify a key sequence that must be entered in order to wake up the system.

The key sequence can consist of up to 6 alphanumeric characters and some special characters. Function keys and modifier keys (such as Ctrl, Alt, Del, etc.) cannot be used.

3.6.6.5. Resume on Software RTC Alarm

Resume on Software RTC Alarm should only be used if the FliteDeck®¹ S5 resume function will be used on the system. When Resume on Software RTC Alarm is enabled, **Resume on RTC Alarm** will be disabled.

**Note:**

1. FliteDeck is a system management suite developed by VIA Technologies, Incorporated.

3.6.6.6. Resume on RTC Alarm

Resume on RTC Alarm can only be used if **Resume on Software RTC Alarm** is not enabled. This feature enables the BIOS to automatically power on the system at a scheduled time. When enabled, the **RTC Alarm Date** and **System Time** features will be unlocked.

3.6.6.7. RTC Alarm Date (Days)

The RTC Alarm Date feature is visible only when **Resume on RTC Alarm** is enabled. This feature enables the user to specify a specific date each month or daily recurrence. Use the + and - keys on the number pad to change the value of the RTC Alarm Date.

Every Day

The Every Day option triggers the RTC Alarm daily.

1 – 31

When a specific numeric date is selected, the RTC Alarm will be triggered on that day of the month.

3.6.6.8. System Time

The System Time option enables the user to specify the time the system should power on for the date that is set in **RTC Alarm Date**.

3.6.7. Spread Spectrum Configuration

The Spread Spectrum Configuration screen enables access to the CPU Spread Spectrum Setting feature.




Figure 29: Illustration of Spread Spectrum Configuration screen

3.6.7.1. Spread Spectrum Setting

The CPU Spread Spectrum Setting feature enables the BIOS to modulate the clock frequencies originating from the mainboard. This feature has two settings: Enabled and 0.1%.

3.6.8. USB Configuration

The USB Configuration screen shows the number of connected USB devices. Additionally, support for various USB features can be enabled or disabled.




Figure 30: Illustration of USB Configuration screen

3.6.8.1. OnChip UHCI Device

The OnChip UHCI Device feature enables support for USB 1.1 devices. UHCI corresponds with the USB_1 stack. UCHI2 corresponds with the USB_2 stack. UCHI3 corresponds with the USB_3 pin header block. UCHI4 corresponds with the USB_4 pin header block.

3.6.8.2. OnChip EHCI Device

The OnChip EHCI Device feature enables support for USB 2.0 devices on USB_1, USB_2, USB_3, and USB_4.

3.6.8.3. Legacy USB Support

The Legacy USB Support feature has two options: "Enabled" and "Auto". When set to "Enabled", the system enables support for legacy USB devices. When set to "Auto", the system automatically disables legacy support if no USB Devices are connected.

3.6.8.4. USB 2.0 Controller Mode

Configures the USB 2.0 controller in FullSpeed or HiSpeed. The FullSpeed limit the USB 2.0 controller to transfer data at 12 Mbps. The HiSpeed enables the USB 2.0 controller to transfer data at 480Mbps. The connected USB device must support HiSpeed in order to benefit from this setting.

3.6.9. CRB Configuration

The CRB Configuration screen includes several chipset settings.




Figure 31: Illustration of CRB Configuration screen

3.6.9.1. VIA USB Wireless LAN Control

This feature enables support for USB wireless LAN control: This feature has two options: "Enabled" and "Disabled".

3.7. Advanced PCI/PnP Settings

The Advanced PCI/PnP Settings screen shows the features that relate to PCI bus and Plug and Play devices. Only change these settings if a PCI or Plug and Play device requires it.

BIOS SETUP UTILITY	
Main	Advanced
<div> <div> Advanced PCI/PnP Settings </div> <div> <div> <div> Clear NVRAM during System Boot. </div> <div> Clear NVRAM [No] </div> <div> Plug & Play O/S [No] </div> <div> PCI Latency Timer [64] </div> <div> Allocate IRQ to PCI VGA [Yes] </div> <div> Palette Snooping [Disabled] </div> <div> PCI IDE BusMaster [Enabled] </div> <div> OffBoard PCI/ISA IDE Card [Auto] </div> <div> IRQ3 [Available] </div> <div> IRQ4 [Available] </div> <div> IRQ5 [Available] </div> <div> IRQ7 [Available] </div> <div> IRQ9 [Available] </div> <div> IRQ10 [Available] </div> <div> IRQ11 [Available] </div> </div> <div> <div> ←→ Select Screen </div> <div> ↑↓ Select Item </div> <div> + - Change Option </div> <div> F1 General Help </div> <div> F10 Save and Exit </div> <div> ESC Exit </div> </div> </div> </div>	

Figure 32: Illustration of Advanced PCI/PnP Settings screen

3.7.1. Clear NVRAM

The Clear NVRAM feature will erase all contents of the non-volatile random access memory when booting up the system. There are two options for this feature: yes and no.

3.7.2. Plug & Play O/S

The Plug & Play O/S feature determines whether the operating system or the BIOS controls the configuration of Plug and Play devices. There are two options for this feature.

Yes

The “Yes” option forces the BIOS to ignore any resource conflicts and enables the installed operating system to configure Plug and Play devices.

No

The “No” option gives the BIOS control over handling resource conflicts caused by Plug and Play devices.

3.7.3. PCI Latency Timer

The PCI Latency Timer feature enables the user to specify the number of PCI bus cycles a connected PCI device can control before handing control of the PCI bus to the next PCI device waiting to use it. Generally, longer cycles increase PCI performance. The available cycles range from 32 to 248 in increments of 32.

3.7.4. Allocate IRQ to PCI VGA

The Allocate IRQ to PCI VGA feature determines whether graphics cards on the PCI bus can access IRQs. This feature has two options.

Yes

The “Yes” option enables the BIOS to respond to a request for an IRQ by a connected PCI VGA card.

No

The “No” option forces the BIOS to ignore all requests for IRQ by a connected PCI VGA card.

3.7.5. Palette Snooping

The Palette Snooping feature should be enabled if video decoder cards are being used in the system. When enabled, video decoder cards can retrieve information about the color palette being used by the system's graphics controller. This feature has two options: "Enabled" and "Disabled".

3.7.6. PCI IDE BusMaster

The PCI IDE BusMaster feature enables IDE controllers on the PCI bus to directly communicate with IDE hard disks connected to PCI IDE cards. This feature has two options: "Enabled" and "Disabled".

3.7.7. OffBoard PCI/ISA IDE Card

Some PCI IDE cards may require this to be set to the PCI slot number (PCI Slot 1~6) that is holding the card.

Auto: Works for most PCI IDE cards.

3.7.8. IRQ3~15

The available IRQs range from 3 to 15. However, not all IRQs in the range are available. IRQs 3, 4, 5, 7, 9, 10, 11, 14, and 15 can be set as either "Available" or "Reserved". When set to "Available", any connected PCI or Plug and Play device can use the IRQ.

3.7.9. DMA Channel 0~7

The available DMA Channels range from 0 to 7. However, not all DMA Channels in the range are available. DMA Channels 0, 1, 3, 5, 6, and 7 can be set as either "Available" or "Reserved". When set to "Available", any connected PCI or Plug and Play device can use the DMA Channel.

3.7.10. Reserved Memory Size

The Reserved Memory Size feature enables the user to reserve a portion of the Upper Memory Area for use by legacy devices. The available sizes are 16k, 32k, and 64k. This feature can also be disabled.

3.7.11. HotPlug Reserve I/O Port Size

The HotPlug Reserve I/O Port Size feature enables the user to set aside a specified portion of the I/O port block for hot-swappable or CardBus devices. The available options range from 4k to 28k in increments of 4k. There is also an "Auto" option for enabling the BIOS to dynamically choose the size to reserve.

3.7.12. HotPlug Reserve Memory Size

The HotPlug Reserve Memory Size feature enables the user to set aside a specified portion of the memory block for hot-swappable or CardBus devices. The available options range from 8MB to 512MB. There is also an "Auto" option for enabling the BIOS to dynamically choose the size to reserve.

3.7.13. HotPlug Reserve PFMemory Size

The HotPlug Reserve PFMemory Size feature enables the user to set aside a specified portion of the pre-fetch memory block for hot-swappable or CardBus devices. The available options range from 32MB to 2048MB. There is also an "Auto" option for enabling the BIOS to dynamically choose the size to reserve.

3.8. Boot Settings

The Boot Settings screen has one link that goes to the **Boot Settings Configuration** screen.




Figure 33: Illustration of Boot Settings screen

3.8.1. Boot Settings Configuration

The Boot Settings Configuration screen has several features that can be run during the system boot sequence.




Figure 34: Illustration of Boot Settings Configuration screen

3.8.1.1. Quick Boot

The Quick Boot feature enables the BIOS to skip certain tests in order to speed up the boot sequence. This feature has two options: "Enabled" and "Disabled".

3.8.1.2. Quiet Boot

The Quiet Boot feature hides all of the Power-on Self Test (POST) messages during the boot sequence. Instead of the POST messages, the user will see an OEM logo. This feature has two options: enabled and disabled.

3.8.1.3. AddOn ROM Display Mode

The AddOn ROM Display Mode feature determines whether or not information from option ROMs is displayed during the boot sequence. There are two options for this feature: "Force BIOS" and "Keep Current". The "Force BIOS" option ensures that all information from option ROMs is displayed.

3.8.1.4. Bootup Num-Lock

The Bootup Num-Lock feature determines how the 10-key pad will behave. When the feature is enabled, the 10-key pad will behave as a number pad. When the feature is disabled, the 10-key pad will behave as cursor navigation keys.

3.8.1.5. Wait for 'F1' if Error

This feature determines how the system will respond if an error is detected during the boot sequence. If this feature is enabled, the BIOS will pause booting and wait for the user to press F1 to enter the BIOS setup menu. This feature has two options: enabled and disabled.

3.8.1.6. Hit 'DEL' Message Display

This feature determines if the BIOS will display a POST message that informs the user how to access the BIOS Setup Utility.¹ This feature has two options: enabled and disabled.



Note:

1. If the Quiet Boot option is enabled, the settings of this feature will have no effect.

3.8.1.7. Interrupt 19 Capture

The Interrupt 19 Capture feature enables hard drives attached to add-on host adaptors (e.g., SCSI cards, eSATA cards, etc) to function as bootable hard drives. Enabling this feature will also grant access to any existing ROM BIOS utilities on the host adapter. This feature has two options: "Enabled" and "Disabled".

3.9. Security Settings

The Security Settings screen provides a way to restrict access to the BIOS or even the entire system.




Figure 35: Illustration of Security Settings screen

3.9.1. Change Supervisor Password

This option is for setting a password for accessing the BIOS setup utility. When a password has been set, a password prompt will be displayed whenever the BIOS setup utility is launched. This prevents an unauthorized person from changing any part of the system configuration.

When a supervisor password is set, the **Password Check** option will be unlocked.

3.9.2. Password Check

This feature is compulsory when the **Change Supervisor Password** option is set. The user will have up to three chances to enter the correct password before the BIOS forces the system to stop booting. If the user does not enter the correct password, the keyboard will also lock up. The only way to get past this is to do a hard reboot (i.e., use the system reset button or cut off the power to the system). A soft reboot (i.e., Ctrl+Alt+Del) will not work because the keyboard will be locked. This feature has two options.

Setup

The Setup option forces users to enter a password in order to access the BIOS Setup Utility.

Always

The Always option forces users to enter a password in order to boot up the system.

3.10. Advanced Chipset Settings

The Advanced Chipset Settings screen has two links for accessing North and South bridge functions. Though the VX900 is a single chip solution, the North and South bridge categories are still for grouping features.




Figure 36: Illustration of Advanced Chipset Settings screen

3.10.1. North Bridge VIA VX900 Configuration

The North Bridge VIA VX900 Configuration screen contains four links to sub-screens and three features.




Figure 37: Illustration of North Bridge VIA VX900 Configuration screen

3.10.1.1. NB HDAudio Codec 1

The NB HDAudio Codec 1 feature enables the BIOS to control the high definition audio codec in the chipset. This feature has two options: "Enable" and "Disable".

3.10.1.2. DRAM Clock/Timing Configuration

The DRAM Clock/Timing Configuration screen has one feature for controlling the system DRAM. All other DRAM features are automated and cannot be accessed.

BIOS SETUP UTILITY	
Chipset	
DRAM Frequency/Timing Configuration	
DRAM Clock	[Auto]
Bank Interleave	[SPD]
Output Impedance Control	[Normal]
DDR2 Memory Chip ODT [DDR2/DDR]	[Auto]
DDR3 Dynamic ODT	[Auto]
BA0 SEL	[A13]
BA1 SEL	[A14]
BA2 SEL	[A15]
VR Interleave Address Bit 0	[A17]
VR Interleave Address Bit 1	[A16]
Virtual Rank Interleave	[Auto]
BA Scramble	[Enabled]
RDRDY	[Default]
Conversion Circuit	[Auto]
DRAM 32-Bit data width	[Disabled]
DramInitMethod	[Force_SW]
Dram Self Refresh	[Enabled]
Dynamic CKE	[Enabled]

Options	
Auto	
400 MHz	
533 MHz	
↔	Select Screen
↑ ↓	Select Item
+ -	Change Option
F1	General Help
F10	Save and Exit
ESC	Exit

V02.69 (C) Copyright 1985-2010, American Megatrends, Inc.

Figure 38: Illustration of DRAM Frequency/Timing Configuration screen

3.10.1.2.1. DRAM Clock

The DRAM Clock option enables the user to determine how the BIOS handles the memory clock frequency. The memory clock can either be dynamic or static. This feature has three options.

Auto

The Auto option enables the BIOS to select a compatible clock frequency for the installed memory.

400 MHz

The 400 MHz option forces the BIOS to be fixed at 800 MHz for DDR3 memory modules.

533 MHz

The 533 MHz option forces the BIOS to be fixed at 1066 MHz for DDR3 memory modules.

3.10.1.3. OnChip VGA Configuration

The OnChip VGA Configuration screen has features for controlling the integrated graphics controller in the VX900 chipset.




Figure 39: Illustration of OnChip VGA Configuration screen

3.10.1.3.1. Hide D1F1

This feature has 2 options: "Disabled" and "Enabled".

3.10.1.3.2. VGA Share Memory (Frame Buffer)

The VGA Share Memory feature enables the user to choose the amount of the system memory to reserve for use by the integrated graphics controller. The amount of memory that can be reserved ranges from 64 – 512 MB.

3.10.1.3.3. CPU Direct Access Frame Buffer

The CPU Direct Access Frame Buffer feature enables the CPU to write to the portion of memory reserved for the integrated graphics controller. This feature has two options: "Disabled" and "Enabled".

3.10.1.3.4. Select Display Device Control

This feature has 2 options: "Auto" and "Manual".

3.10.1.3.5. Select Display Device 1 and 2

The Select Display Device feature enables the user to choose a specific display interface. This feature has four options: CRT, LCD, HDMI® and DP. If both Select Display Device 1 and Select Display Device 2 are set to the same interface, then any display device connected to the other interface will not function. For example, if both Select Display 1 and 2 are set to CRT, then no data will be sent to the HDMI®, LCD and DP port.

3.10.1.3.6. Panel Type

The Panel Type feature enables the user to specify the resolution of the display being used with the system. The panel types are predefined in the VGA VBIOS.

Panel Type	Resolution	Panel Type	Resolution
00	640 × 480	08	800 × 480
01	800 × 600	09	1024 × 600
02	1024 × 768	10	1366 × 768
03	1280 × 768	11	1600 × 1200
04	1280 × 1024	12	1680 × 1050
05	1400 × 1050	13	1920 × 1200
06	1440 × 900	14	1920 × 1080
07	1280 × 800	15	1024 × 576

3.10.1.3.7. Backlight Control by VX900

The Backlight Control feature control by VX900 enables the user to control the brightness of the LCD backlight. This feature has five options.

Level 1 0% PW Duty

Level 1 25% PW Duty

Level 2 50% PW Duty

Level 3 75% PW Duty

Level 4 100% PW Duty

3.10.1.3.8. Backlight Control by AD5301

The Backlight Control feature control by AD5301. This feature has five options.

Level 0 0.00V

Level 1 1.25V

Level 2 2.50V

Level 3 3.75V

Level 4 5.00V

3.10.1.4. PCIE-NB Configuration

The PCIE-NB Configuration screen has features for controlling the PCIE Express interface in the VX900 chipset.




Figure 40: Illustration of PCIE-NB Configuration screen

3.10.1.4.1. Reset PCIE When Link Fail

This feature has 2 options: "Enabled" and "Disabled".

3.10.1.4.2. Reset PE0 When Link Fail

This feature has 2 options: "Enabled" and "Disabled".

3.10.1.4.3. Reset PE1 When Link Fail

This feature has 2 options: "Enabled" and "Disabled".

3.10.1.4.4. Reset PE2 When Link Fail

This feature has 2 options: "Enabled" and "Disabled".

3.10.1.4.5. Reset PE3 When Link Fail

This feature has 2 options: "Enabled" and "Disabled".

3.10.1.4.6. PCIE Target Link Speed

This feature has 2 options: "Auto" and "Force Gen1".

3.10.1.4.7. PCIE Root Port

This feature has 2 options: "Enabled" and "Disabled".

3.10.1.4.8. PCIE PE0 Control

This feature has 2 options: "Enabled" and "Disabled".

3.10.1.4.9. PCIE PE1 Control

This feature has 2 options: "Enabled" and "Disabled".

3.10.1.4.10. PCIE PE2 Control

This feature has 2 options: "Enabled" and "Disabled".

3.10.1.4.11. PCIE PE3 Control

This feature has 2 options: "Enabled" and "Disabled".

3.10.2. South Bridge VIA VX900 Configuration

The South Bridge VIA VX900 Configuration screen has the following features.




Figure 41: Illustration of South Bridge VIA VX900 Configuration screen

3.10.2.1. SATA Gen2 Support

The SATA Gen2 Support feature enables the BIOS to determine whether SATA 3Gbps or 1.5Gbps specifications are followed. This feature has two options: "Enabled" or "Disabled".

3.10.2.2. OnChip HDAC Device

The OnChip HDAC Device feature enables the BIOS to control the high definition audio codec in the chipset. This feature has two options: "Enable" or "Disable".

3.10.2.3. Serial ATA Controller

The Serial ATA Controller feature enables the BIOS to turn the SATA controller in the chipset ON or OFF. This feature has two options: "Enabled" or "Disabled".

3.10.2.4. OnChip UART Mode

This feature has two options: "Enabled" or "Disabled".

3.10.2.5. SDIO Host Controller

This feature has two options: "Enable" or "Disable".

3.10.2.6. HPET Support

The HPET Support feature enables the BIOS to determine if the high precision event timer in the chipset is ON or OFF. This feature has two options: "Enabled" or "Disabled".

3.10.2.7. WATCHDOG Timer Enable

The WATCHDOG Timer Enable feature unlocks three other features that enable the BIOS to monitor the state of the system. This feature has two options: "Enabled" or "Disabled".

3.11. Exit Options




Figure 42: Illustration of Exit Options screen

3.11.1. Save Changes and Exit

Save all changes to the BIOS and exit the BIOS Setup Utility. The “F10” hotkey can also be used to trigger this command.

3.11.2. Discard Changes and Exit

Exit the BIOS Setup Utility without saving any changes. The “Esc” hotkey can also be used to trigger this command.

3.11.3. Discard Changes

Undo the previous changes.

3.11.4. Load Optimal Defaults

Load optimal default values for all the setup items. The default optimized values are defined by the mainboard manufacturer to provide optimized environment for a basic system.

4. Software and Technical Supports

4.1. Microsoft and Linux Support

The VIA COMe-8X92 mainboard is highly compatible with Microsoft Windows and Linux operating systems.

4.1.1. Driver Installation

4.1.1.1. Microsoft Driver Support

The latest Windows drivers can be downloaded from the VIA website at www.viatech.com

4.1.1.2. Linux Driver Support

Linux drivers are provided through various methods including:

- Drivers provided by VIA
- Using a driver built into a distribution package
- Visiting www.viatech.com for the latest updated drivers
- Installing a third party driver (such as the ALSA driver from the Advanced Linux Sound Architecture project for integrated audio)

4.2. Technical Supports and Assistance

- For utilities downloads, latest documentation and new information about the COMe-8X92, go to <http://www.viatech.com/en/products/boards/modules/>
- For technical support and additional assistance, always contact your local sales representative or board distributor, or go to <http://www.viatech.com/en/service/contact.jsp> to fill up the form request.
- For OEM clients and system integrators developing a product for long term production, other code and resources may also be made available. Contact VIA to submit a request.

Appendix A. COMEDB2 Carrier Board

A.1. Board Specifications

- **COM Express™ Module Type**
 - Supports COM Express™ Type 6
- **Audio**
 - VIA VT1828S High Definition Audio Codec
- **Super I/O**
 - VIA VT1211 LPC Super I/O
- **BIOS**
 - AMI BIOS
 - 4/8Mbit LPC Flash BIOS, PLCC 32 pin or SPI BIOS
- **Front Panel I/O**
 - 1 x SD card slot (SDIO), shared with DIO1 pin header
- **Rear Panel I/O**
 - 1 x VGA port
 - 1 x COM port
 - 1 x DisplayPort (DP2)
 - 1 x HDMI® port
 - 4 x USB 3.0 ports
 - 1 x Gigabit Ethernet port
 - 6 x Audio jacks (supports multi-channel audio outputs)
- **Onboard Slots, Buttons and Power Connectors**
 - 1 x ATX power connector
 - 1 x AUX power connector
 - 1 x miniPCIe slot
 - 1 x Power button
 - 1 x Reset button
 - 2 x SATA connectors
 - 1 x Reserved PCIe x4 slot for DVP
 - 1 x Reserved PCIe x4 slot for VCP
 - 2 x PCIe x1 slots
 - 1 x PCIe x16 (supports 4 lane) slot PEG
- **Onboard Pin Headers and Connectors**
 - 1 x COM2 pin header, add +5V/+12V power select option on RI pin
 - 1 x LPT pin header
 - 1 x SPI pin header
 - 1 x LPC pin header
 - 1 x DIO1 pin header, shared with SDIO port

- 1 x DIO2 pin header (from VIA VT1211)
- 1 x SMBus pin header
- 1 x I²C pin header
- 2 x USB 2.0 pin headers for USB 2.0 port 0~3
- 1 x Front LAN LED pin header
- 1 x Front Audio pin header
- 1 x Front Panel pin header (for HDD LED, Power LED, Switch and Speaker)
- 1 x CD-In connector
- 1 x System sensor pin header
- 1 x CPU fan connector
- 1 x System fan connector
- 1 x Serial Port pin header
- 1 x Inverter connector
- 1 x LVDS panel connector
- 1 x S/PDIF connector
- **Onboard Jumpers**
 - 1 x Clear CMOS jumper
 - 1 x Inverter power select jumper
 - 1 x LCD panel power select jumper
 - 2 x BIOS type select jumpers (for selecting LPC/SPI BIOS)
 - 2 x BIOS select jumpers (for selecting module/carrier board BIOS)
 - 2 x COM voltage select jumpers
 - 1 x TV/DVP select jumper
 - 2 x USB 2.0 port select jumpers
 - 1 x USB 2.0 to miniPCle slot select jumper
- **Form Factor and Dimension**
 - Micro-ATX
 - 10" x 9.6"
- **Operating Temperature**
 - 0°C ~ 60°C
- **Storage Temperature**
 - -40°C ~ 70°C
- **Operating and Storage Humidity**
 - 0% ~ 95% relative humidity

A.2. External I/O Connectors

The COMEDB2 has a wide selection of interfaces. It includes a selection of frequently used ports as part of the external I/O coastline.

A.2.1. Front Panel I/O




Figure 43: Front panel I/O

A.2.2. Rear Panel I/O




Figure 44: Rear panel I/O

A.3. COMEDB2 Layout Diagram

A.3.1. Onboard Slots, Buttons and Power Connectors




Figure 45: COMEDB2 slots buttons and power connectors layout

A.3.2. Onboard Pin headers and Connectors




Figure 46: COMEDB2 pin headers and connectors

Item	Description
1	CD_IN: CD-In connector from CD drive
2	F_AUDIO: Front audio pin header
3	COM2: COM2 pin header
4	LPT: LPT pin header
5	SYS_SEN: System sensor pin header
6	LPC: LPC pin header
7	DIO2: DIO2 pin header
8	CPUFAN: CPU fan connector
9	USB2_0/1: USB 2.0 pin header for port 0 and 1
10	SPI: SPI pin header
11	SER_PORT: Serial Port pin header
12	USB2_2/3: USB 2.0 pin header for port 2 and 3
13	INVERTER: Inverter connector
14	LVDS: LVDS panel connector
15	SYSFAN: System fan connector
16	DIO1: DIO1 connector
17	I2C_BUS: I ² C pin header
18	SMBUS: System Management Bus pin header


19	F_PANEL: Front Panel pin header
20	SPDIF: S/PDIF connector
21	F_PANEL: Front LAN LED pin header

Table 3: Layout diagram description table of the COMEDB2 (pin headers and connectors)

A.3.2.1. Pin Headers and Connectors pin definition

1 CD_IN

1	CD_IN_L
2	CD_IN_GND
3	CD_IN_GND
4	CD_IN_R



2 F_AUDIO

MIC2_FR_L	1		2	AGND
MIC2_FR_R	3		4	FNT_DET
HP_OUT_R	5		6	MIC2_JD
FNT_IO_SENSE	7		8	KEY
HP_OUT_L	9		10	LINE2_JD
+12V	11		12	+12V
AGND	13		14	AGND

3 COM2

COM_DCD2	1		2	COM_RXD2
COM_TXD2	3		4	COM_DTR2
GND	5		6	COM_DSR2
COM_RTS2	7		8	COM_CTS2
COM_RI2	9		10	KEY


4 LPT

-LP_STB	1		2	-LP_AFD
LP_D0	3		4	-LP_ERR
LP_D1	5		6	-LP_INIT
LP_D2	7		8	-LP_SLIN
LP_D3	9		10	GND
LP_D4	11		12	GND
LP_D5	13		14	GND
LP_D6	15		16	GND
LP_D7	17		18	GND
-LP_ACK	19		20	GND
LP_BUSY	21		22	GND
LP_PE	23		24	GND
LP_SLCT	25		26	KEY


5 SYS_SEN

1	DTDP	
2	DTDP	
3	GND	

6 LPC

LPC_AD1	1		2	LPC_33M_CLK
-LPC_RESET	3		4	GND
LPC_AD0	5		6	NC
LPC_AD2	7		8	-LPC_FRAME
LPC_SERIRQ	9		10	LPC_AD3
-LPC_DRQ1	11		12	NC
+5V	13		14	+3.3V
+5V	15		16	+3.3V
GND	17		18	GND
GND	19		20	KEY


7 DIO2

5V_DIO2	1		2	12V_DIO2
SIO_GPO30	3		4	SIO_GPI34
SIO_GPO31	5		6	SIO_GPI35
SIO_GPO32	7		8	SIO_GPI36
SIO_GPO33	9		10	SIO_GPI37
GND	11		12	GND

8 CPUFAN

1	FANIO	
2	FANPWM	
3	GND	

9 USB2_0/1

VUSB	1		2	VUSB
USBD_T4-	3		4	USBD_T5-
USBD_T4+	5		6	USBD_T5+
GND	7		8	GND
KEY	9		10	W_LESS_LED
GND	11		12	-RF_ON

10 SPI

SPI_VCC	1		2	GND
-SPI_SS0	3		4	SPI_CLK
SPI_DI	5		6	SPI_DO
KEY	7		8	RESET

11 SER_PORT

SER0_TX_CON	1		2	SER0_RX_CON
NC	3		4	NC
GND	5		6	NC
SER1_TX_CON	7		8	SER1_RX_CON
NC	9		10	KEY

12 USB2_2/3

VUSB	1		2	VUSB
USBD_T6-	3		4	USBD_T7-
USBD_T6+	5		6	USBD_T7+
GND	7		8	GND
KEY	9		10	GND

13 Inverter

1	IVDD_IN
2	IVDD_IN
3	BAKLITE_EN
4	BLT_CK
5	BAKLITE_EN
6	BLT_CTRL
7	GND
8	GND




14 LVDS

NC	1		2	PVDD
NC	3		4	PVDD
GND	5		6	GND
NC	7		8	GND
NC	9		10	-A0_L
GND	11		12	A0_L
NC	13		14	GND
NC	15		16	-A1_L
GND	17		18	A1_L
NC	19		20	GND
NC	21		22	-A2_L
GND	23		24	A2_L
NC	25		26	GND
NC	27		28	-CLK1_L
NC	29		30	CLK1_L
NC	31		32	GND
NC	33		34	-A3_L
NC	35		36	A3_L
NC	37		38	SPCLK
NC	39		40	SPD

15 SYSFAN

1	FANIO
2	FANPWM
3	GND



16 DIO1

5V_DIO1	1		2	12V_DIO1
COM_GPO0	3		4	COM_GPI0
COM_GPO1	5		6	COM_GPI1
COM_GPO2	7		8	COM_GPI2
COM_GPO3	9		10	COM_GPI3
GND	11		12	GND

17 I2C BUS

1	I2C_CLK	
2	I2C_DATA	
3	GND	

18 SMBUS

1	SMB_CLK	
2	SMB_DATA	
3	GND	

19 F_PANEL

FP_5V	1		2	FP_3V
FP_5V	3		4	-SATA_LED
-PLED	5		6	-PW_BTN
FP_5V	7		8	GND
NC	9		10	RST_SW
NC	11		12	GND
SPEAK	13		14	FP_5V
KEY	15		16	NC

20 SPDIF

1	+5V	
2	SPDIFO	
3	GND	

21 FLAN_LED

3VSUS	1		2	-LAN_ACT
3VSUS	3		4	NC
GND	5		6	W_LAN_LED
3VSUS	7		8	GND
KEY	9		10	GND

A.3.3. Onboard Jumpers




Figure 47: COMEDB2 jumpers layout

Item	Description
22	BIOS_SEL0: BIOS type select jumper (for selecting LPC/SPI BIOS)
23	BIOS_SEL1: BIOS type select jumper (for selecting LPC/SPI BIOS)
24	JP_COM2_VSEL: COM2 voltage select jumper
25	JP_COM1_VSEL: COM1 voltage select jumper
26	CLEAR_CMOS: Clear CMOS jumper
27	JP_USB3_SEL: USB 2_3 enabled select jumper
28	JP_USB2_SEL: USB 2_2 enabled select jumper
29	IVDD: Inverter power select jumper
30	JP_USBME_SEL: USB port 2 and PCIe slot enabled select jumper
31	BIOS_DIS1: BIOS select jumper (for selecting module/carrier board BIOS)
32	BIOS_DIS0: BIOS select jumper (for selecting module/carrier board BIOS)
33	PVDD: LCD panel power select jumper
34	TV_DVP_SEL: TV and DVP select jumper

Table 4: Layout diagram description table of the COMEDB2 (jumpers)

A.3.3.1. Jumper Settings

22**BIOS_SEL0****23****BIOS_SEL1**

BIOS_SEL0	BIOS_SEL1	
Pins		Description
1-2	2-3	Select SPI BIOS (default)
2-3	1-2	Select LPC BIOS

24**JP_COM2_VSEL**

Pins	Description
1-2	Enabled COM2 pin header to support +5V
2-3	Normal (default)
3-4	Enabled COM2 pin header to support +12V

25**JP_COM1_VSEL**

Pins	Description
1-2	Enabled COM1 pin header to support +5V
2-3	Normal (default)
3-4	Enabled COM1 pin header to support +12V

26**CLEAR_CMOS**

Pins	Description
1-2	Keep CMOS setting (default)
2-3	Clear CMOS setting

27**JP_USB3_SEL**

Pins	Description
1-2	Enabled USB 2.0 Port 3 (USB2_3) (default)
3-4	Enabled USB 2.0 Port 3 (USB2_3) (default)

28 JP_USB2_SEL

Pins	Description
1-2	Enabled USB 2.0 Port 2 (USB2_2) (default)
3-4	Enabled USB 2.0 Port 2 (USB2_2) (default)

Note: For [28] JP_USB2_SEL to be activated, the [30] JP_USBME_SEL function has to be disabled.

29 IVDD

Pins	Description
1-2	Use +5V for the Inverter power.
2-3	Use +12V for the Inverter power (default)

30 JP_USBME_SEL

Pins	Description
1-2	Enabled USB 2.0 port 2 to miniPCle slot
3-4	Enabled USB 2.0 port 2 to miniPCle slot

Note: For [30] JP_USBME_SEL to be activated, the [28] JP_USB2_SEL function has to be disabled.

31 BIOS_DIS1

32 BIOS_DIS0

BIOS_DIS1	BIOS_DIS0	Description
1-2	1-2	Select module SPI BIOS (default)
1-2	2-3	Select carrier board LPC BIOS
2-3	1-2	Select module LPC BIOS
2-3	2-3	Select carrier board SPI BIOS

33 PVDD

Pins	Description
1-2	Use +5V for the LCD panel power.
2-3	Use +3.3V for the LCD panel power (default)

34 TV_DVP_SEL

Pins	Description
1-2	Enabled TTL/TV support from DVP slot
2-3	Plug detect from DVP slot (default)



Taiwan Headquarters

1F, 531 Zhong-zheng Road,
Xindian Dist., New Taipei City 231
Taiwan

Tel: 886-2-2218-5452
Fax: 886-2-2218-9860
Email: embedded@via.com.tw



USA

940 Mission Court
Fremont, CA 94539,
USA

Tel: 1-510-687-4688
Fax: 1-510-687-4654
Email: embedded@viatech.com



Japan

3-15-7 Ebisu MT Bldg. 6F,
Higashi, Shibuya-ku
Tokyo 150-0011
Japan

Tel: 81-3-5466-1637
Fax: 81-3-5466-1638
Email: embedded@viatech.co.jp



China

Tsinghua Science Park Bldg. 7
No. 1 Zongguancun East Road,
Haidian Dist., Beijing, 100084
China

Tel: 86-10-59852288
Fax: 86-10-59852299
Email: embedded@viatech.com.cn



Europe

Email: embedded@via-tech.eu